


# The 1240 Logic Analyzer



The  
**1240**  
Logic Analyzer

OPERATOR'S MANUAL

PLEASE CHECK FOR CHANGE INFORMATION  
AT THE REAR OF THIS MANUAL


---

FIRST PRINTING JUNE 1983  
REVISED PRINTING FEB 1984

**Tektronix**<sup>®</sup>  
COMMITTED TO EXCELLENCE

Copyright © 1983, 1984, Tektronix, Inc. All rights reserved. Contents of this publication may not be reproduced in any form without the written permission of Tektronix, Inc.

Products of Tektronix, Inc. and its subsidiaries are covered by U.S. and foreign patents and/or pending patents.

TEKTRONIX, TEK, SCOPE-MOBILE, and  are registered trademarks of Tektronix, Inc. TELEQUIPMENT is a registered trademark of Tektronix U.K. Limited.

Printed in U.S.A. Specification and price change privileges are reserved.

**Tektronix, Inc.**  
**Walker Road Industrial Park**  
**P.O. Box 4600**  
**Beaverton, Or. 97075**

## MANUAL REVISION STATUS

Product: 1240 Logic Analyzer

This manual supports the following versions of this product: serial numbers B020170 and up.

REV DATE	DESCRIPTION
JUN 1983	Original Issue
JUL 1983	Revised: pages 1-8, 8-5 through 8-9, and 8-22.
OCT 1983	Revised: pages iii, 1-13, 1-15, 1-16, 1-18, 2-1, 2-5, 4-16, 7-1, 7-3, 7-4, 7-5, 8-5, 8-7, 8-18, 8-22, I-3, I-8 Table of Contents on the Config tab page Added: pages 3-24, 8-23.
JAN 1984	Revised: pages iii, 1-16, 1-18, 3-4, 3-6, 3-11, 4-6, 4-7, 7-1, 7-3 to 7-5, 8-5 to 8-10, 8-19, 8-22, 8-23

## TABLE OF CONTENTS

	Page
PREFACE .....	i
LIST OF ILLUSTRATIONS .....	vi
LIST OF TABLES .....	viii
OPERATOR'S SAFETY SUMMARY .....	ix
Section 1	OVERVIEW AND POWER-UP PROCEDURE
GENERAL INFORMATION .....	1-1
KEYBOARD DESCRIPTION .....	1-2
EXECUTE Keys .....	1-2
MENU Keys .....	1-3
Data Entry Keys .....	1-3
Power Switch .....	1-3
Cursor Control Keys .....	1-4
SELECT Keys .....	1-4
SCROLL Knob .....	1-4
MENU OVERVIEW .....	1-5
Menu Soft Keys .....	1-5
Menu Changes .....	1-5
Menu Descriptions .....	1-5
CONFIG Group .....	1-5
TRIGGER Group .....	1-6
DATA Group .....	1-6
EDIT Group .....	1-6
UTILITY Group .....	1-7
Types of Video .....	1-7
POWER-UP PROCEDURE .....	1-8
Initial Inspection .....	1-8
Repacking for Shipment .....	1-8
Power Requirements .....	1-8
Line Voltage Selector .....	1-8
Power Cords .....	1-8
Power Switches .....	1-8
Power-Up Diagnostics .....	1-10
PROBE CONNECTIONS .....	1-13
Pod ID .....	1-13
△ Lead Sets .....	1-13
ROM/RAM AND COMM PACK CONNECTIONS .....	1-16
OPERATOR'S CHECKOUT PROCEDURE .....	1-18
Section 2	DEMONSTRATION
SIMPLE EXAMPLE: A QUICK ACQUISITION .....	2-1
Required Equipment .....	2-1
Probe Connection .....	2-1
Power-Up .....	2-1
Setting Input Thresholds .....	2-1
Defining the Trigger Condition .....	2-2
Acquiring Data .....	2-4
Timing Diagram Display .....	2-4

## PREFACE

This manual describes the Tektronix 1240 Logic Analyzer and the 1240D1 and 1240D2 data acquisition cards. The sample menu displays in this manual are based on a 1240 equipped with two 1240D1s and two 1240D2s.

Operating information for COMMunication, ROM, and RAM packs is not contained in this manual. Refer to the documentation that accompanies these products for complete installation and operating instructions.

Several copies of the *1240 Reference Guide* are provided with each 1240. The *Reference Guide* provides brief descriptions of each 1240 menu and is a valuable quick-reference tool.

## HOW TO USE THIS MANUAL

This manual is designed around the 1240 menu groups, represented by the MENU keys on the front panel. Each menu group has its own section in this manual. Within each section, the menus in the group are described in the order that their soft keys are displayed at the top of the screen, left to right. Other manual sections cover power-up and operator checkout procedures, and general reference information. Section 2 provides several setup examples for first-time users.

Each section in this manual is preceded by a tabbed page so that information can be referenced quickly. Other reference aids include:

- **Manual Table of Contents** — Refer to the Table of Contents, List of Illustrations, and List of Tables at the beginning of this manual for a complete breakdown of the manual.
- **Section Tables of Contents** — Section tables of contents are located on the back of each tab page. Refer to this information for an overview of section contents.
- **Index.** — Refer to the index at the back of the manual for reference to specific subjects.

## TABLE OF CONTENTS (cont.)

	Page
<b>A MORE COMPLICATED EXAMPLE: TWO TIMEBASES AND DEMULTIPLEXING</b>	
Required Equipment	2-5
Probe Connection	2-5
Power-Up	2-5
Operation Level and TPG Mode	2-5
Setting Up the Timebases	2-6
Setting Input Thresholds	2-6
Memory Configuration	2-8
Channel Grouping	2-8
Specifying the Trigger Condition	2-10
Acquiring Data	2-12
Scrolling and Cursors	2-12
Glitch Display ON and OFF (State Table)	2-12
Timing Diagram Display	2-12
Expanding the Timing Diagram	2-13
Glitch Display ON and OFF (Timing Diagram)	2-13
Measuring Time Using the Cursors	2-13
Search Pattern Entry	2-13
Storing a Setup	2-13
Section 3	CONFIG
OPERATION LEVEL	3-1
TIMEBASE	3-3
Active Timebases	3-3
Global Event Recognizer Clocked/Unlocked	3-3
Asynchronous Timebase	3-4
10 ns Acquisition	3-4
Glitches	3-4
Qualification	3-4
Synchronous Timebase	3-6
Demultiplexing	3-7
MEMORY CONFIG	3-10
Pods Acquiring Data	3-10
Memory Width vs. Depth	3-10
Glitch Storage	3-11
Pod-Timebase Assignments	3-11
Demultiplexing	3-11
INPUT POD Field	3-14
TIMEBASE Field	3-14
CHANNEL GROUPING	3-18
Grouping Basics	3-18
Group Name, Input Radix, Display Radix	3-18
POD/CHAN Pairs	3-18
Guidelines for Entering POD/CHAN Pairs	3-21
Building Groups	3-23
CLEAR GROUP	3-23
DELETE CHANNEL	3-23
ADD NEXT CHANNEL	3-23
INSERT CHANNEL	3-23
Channel Grouping Defaults	3-23
Demultiplexing	3-24

## TABLE OF CONTENTS (cont.)

		Page
Section 4	TRIGGER	
	TRIGGER SPEC .....	4-1
	Trigger Position .....	4-1
	External Trigger Out .....	4-3
	Global Event Recognizer .....	4-5
	Overview .....	4-5
	Filter .....	4-5
	Clocked/Unlocked .....	4-5
	Counter/Timer .....	4-5
	Storage Qualification .....	4-8
	Sequential Event Recognizer .....	4-8
	Overview .....	4-8
	Filter .....	4-9
	Storage Qualification .....	4-9
	Edge vs. Level Event Recognition .....	4-10
	Level .....	4-10
	Edge .....	4-10
	Building a Sequence .....	4-12
	DEFAULT TRIGGER SPEC .....	4-12
	DELETE LEVEL .....	4-12
	LOAD FROM ACTIVE CURSOR .....	4-12
	ADD LEVEL .....	4-12
	Starting the Trigger Search & Evaluating Status Displays .....	4-12
	AUTO-RUN SPEC .....	4-15
	COMPARE ACQMEM TO REFMEM .....	4-15
	CONTINUOUS TRIGGER OUT .....	4-16
	TRIGGER IN .....	4-16
	STORE AFTER TRIGGER .....	4-19
Section 5	DATA	
	COMMON DATA DISPLAY FEATURES .....	5-1
	Data Scrolling and Cursor Control .....	5-1
	Trigger Display .....	5-1
	Glitch Display .....	5-4
	Data Correlation .....	5-4
	Highlighting .....	5-4
	Searching for a Data Pattern .....	5-5
	Acquisition Memory (ACQMEM) and Reference	
	Memory (REFMEM) .....	5-5
	Memory Configuration Requirements .....	5-8
	Blank Areas in the Data Display .....	5-8
	FEATURES SPECIFIC TO THE STATE TABLE .....	5-9
	Data Display Truncation .....	5-9
	FEATURES SPECIFIC TO THE TIMING DIAGRAM .....	5-10
	EXPANSION Field .....	5-10
	Memory Window .....	5-10
	PAGE Field .....	5-10



## TABLE OF CONTENTS (cont.)

		Page
Section 6	EDIT	
	SEARCH PATTERN ENTRY .....	6-1
	EDIT LINE VALUE Field .....	6-1
	CLEAR PATTERN .....	6-1
	DELETE LINE .....	6-4
	ADD LINE .....	6-4
	LOAD FROM ACTIVE CURSOR .....	6-4
	REFERENCE MEMORY EDITOR .....	6-5
Section 7	UTILITY	
	STORAGE MEMORY MANAGER .....	7-1
	Storing Files .....	7-1
	Retrieving Files .....	7-1
	INIT .....	7-1
	Nonvolatile Memory .....	7-4
	Internal RAM .....	7-4
	ROM Packs .....	7-4
	RAM Packs .....	7-4
Section 8	REFERENCE INFORMATION	
	EFFECTS OF MENU CHANGES .....	8-1
	SPECIFICATIONS .....	8-5
	ERROR AND PROMPT MESSAGES .....	8-11
	DIFFERENCES BETWEEN OPERATION LEVELS .....	8-17
	TEST PATTERN GENERATOR INFORMATION .....	8-18
	OCTAL-HEX-ASCII CONVERSION CHART .....	8-20
	OCTAL-HEX-EBCDIC CONVERSION CHART .....	8-21
	OPTIONS AND ACCESSORIES .....	8-22

## LIST OF ILLUSTRATIONS

	Page
1-1 1240 keyboard layout .....	1-2
1-2 Menu overview diagram, list of menus accessed by each MENU key	1-4
1-3 1240 back panel .....	1-9
1-4 Example display generated when a failure is detected by the power-up diagnostics .....	1-12
1-5 Connecting probes to the 1240 .....	1-14
1-6 Connecting lead sets and ground leads to data acquisition probes .	1-15
1-7 Installing a ROM or RAM pack .....	1-16
1-8 Installing a COMM pack .....	1-17
2-1 Map of the TPG outputs and how the diagnostic lead sets connect to them .....	2-2
2-2 1240 power-up display with one 9-channel and one 18-channel acquisition card installed .....	2-3
2-3 Data acquired at 20 ns ASYNC after triggering on FF in the TPG pattern .....	2-3
2-4 Timing diagram display of data acquired at 20 ns ASYNC after triggering on FF in the TPG pattern .....	2-4
2-5 Setup of the Timebase menu for the second example .....	2-7
2-6 Setup of the Memory Config menu for the second example .....	2-7
2-7 Setup of the 9-channel portion of the Channel Grouping menu for the second example .....	2-9
2-8 Setup of the 18-channel portion of the Channel Grouping menu for the second example .....	2-10
2-9 Setup of the Trigger Spec menu for the second example .....	2-11
2-10 Data display of TPG output triggered on a sequential event recog- nizer value of 1FF on timebase 1, followed by a 1FF, 1F7 on timebase 2 .	2-11
3-1 Operation Level menu power-up default display .....	3-1
3-2 Timebase menu: specifying an ASYNC or a SYNC timebase .....	3-5
3-3 Demonstration of Global Event Recognizer UNLOCKED .....	3-6
3-4 Timebase menu: description of T2 DEMUX fields .....	3-8
3-5 Setting up timebases for demultiplexing, three examples .....	3-9
3-6 Memory Config default display .....	3-12
3-7 Memory Config display illustrating memory chaining .....	3-16
3-8 Memory Config example demultiplexing setup .....	3-17
3-9 Default 9-channel grouping when two 9-channel cards are installed .	3-19
3-10 Sample 18-channel grouping arrangement .....	3-22
4-1 Power-up default Trigger Spec menu display .....	4-2
4-2 Two-timebase Trigger Spec display .....	4-4
4-3 Difference between edge and level event recognition .....	4-11
4-4 WAITING FOR TRIGGER status display .....	4-13
4-5 TRIGGERED status display .....	4-14
4-6 Menu display for the COMPARE ACQMEM TO REFMEM Auto-Run condition .....	4-17
4-7 Menu displays for the CONTINUOUS TRIGGER OUT, TRIGGER IN, and STORE AFTER TRIGGER Auto-Run conditions .....	4-19
4-8 Status display for COMPARE ACQMEM TO REFMEM actions: DISPLAY AND STOP, DISCARD AND REACQUIRE .....	4-20
4-9 Status display for COMPARE ACQMEM TO REFMEM, DISPLAY AND REACQUIRE action .....	4-21
5-1 One-timebase State Table display with glitches .....	5-2
5-2 Explanation of the 1240 data correlation feature .....	5-6
5-3 Two-timebase State Table display with truncated data .....	5-7

## LIST OF ILLUSTRATIONS (cont.)

		<b>Page</b>
5-4	Some causes of blank areas in the data displays .....	5-9
5-5	Timing Diagram display with glitches .....	5-11
5-6	Timing Diagram display of data acquired with two timebases .....	5-13
6-1	Sample Search Pattern Entry menu display .....	6-2
6-2	Sample Reference Memory Editor menu display .....	6-6
7-1	Sample Storage Memory Manager display without a RAM or ROM pack .....	7-2
7-2	Sample Storage Memory Manager display when a RAM pack is installed .....	7-5
8-1	Mode 0 and mode 2 TPG outputs .....	8-19
8-2	Mode 1 and mode 3 TPG outputs .....	8-19

## LIST OF TABLES

		Page
1-1	Power-Up Error Conditions .....	1-10
3-1	Memory Width vs. Depth Selections for 9-Channel Cards (Operation Levels 1-3) .....	3-14
3-2	Memory Width vs. Depth Selections for 18-Channel Cards (Operation Levels 1-3) .....	3-15
3-3	Timebase Selections for Pod-Timebase Assignments in the Memory Config Menu (Operation Levels 2 and 3) .....	3-15
3-4	Applying the Display Radix to Acquired Data .....	3-21
4-1	Trigger Positions Based on Memory Size .....	4-3
4-2	Global Event Recognizer Actions and Associated Fields .....	4-6
4-3	Sequential Event Recognizer Actions and Associated Fields .....	4-7
4-4	Summary of Sequential Event Recognizer Actions .....	4-10
4-5	Conditions That Determine Edge Event Recognition .....	4-11
4-6	Trigger In: Combinations of EXT TRIG IN/OUT BNCs .....	4-16
8-1	Effects of Changes to the Operation Level Menu .....	8-1
8-2	Effects of Changes to the Timebase Menu .....	8-2
8-3	Effects of Changes to the Memory Config Menu .....	8-3
8-4	Effects of Changes to the Channel Grouping Menu .....	8-4
8-5	1240 Electrical Specifications .....	8-5
8-6	1240 Environmental Specifications .....	8-7
8-7	1240 Physical Specifications .....	8-7
8-8	1240D1 Electrical Specifications .....	8-8
8-9	1240D2 Electrical Specifications .....	8-9
8-10	Differences Between the Operation Levels .....	8-17
8-11	TPG Pattern from Left Connector .....	8-18
8-12	TPG Pattern from Right Connector .....	8-18
8-13	TPG Modes .....	8-18

## OPERATOR'S SAFETY SUMMARY

Specific warnings and cautions will be found throughout the manual where they apply, but may not appear in this summary.

### TERMS

**In This Manual.** CAUTION statements identify conditions or practices that could result in damage to the equipment or other property.

WARNING statements identify conditions or practices that could result in personal injury or loss of life.

**As Marked on Equipment.** CAUTION indicates a personal injury hazard not immediately accessible as one reads the marking, or a hazard to property including the equipment itself.

DANGER indicates a personal injury hazard immediately accessible as one reads the marking.

### SYMBOLS

#### In This Manual



This symbol indicates where applicable cautionary or other information is to be found.

#### As Marked on Equipment



DANGER — High voltage.



Protective ground (earth) terminal.



ATTENTION — refer to manual.

### POWER SOURCE

This product is intended to operate from a power source that does not apply more than 250 volts rms between the supply conductors or between either supply conductor and ground. A protective ground connection by way of the grounding conductor in the power cord is essential for safe operation.

### GROUNDING THE PRODUCT

This product is grounded through the grounding conductor of the power cord. To avoid electrical shock, plug the power cord into a properly wired receptacle before connecting to the product input or output terminals. A protective-ground connection by way of the grounding conductor in the power cord is essential for safe operation.

### DANGER ARISING FROM LOSS OF GROUND

Upon loss of the protective-ground connection, all accessible conductive parts (including knobs and controls that may appear to be insulated) can render an electric shock.

## **1240 Operator's**

### **USE THE PROPER POWER CORD**

Use only the power cord and connector specified for your product. Use only a power cord that is in good condition.

### **USE THE PROPER FUSE**

To avoid fire hazard, use only the fuse of correct type, voltage rating and current rating as specified in the parts list in the *1240 Service Manual*.

Refer fuse replacement to qualified service personnel.

### **DO NOT OPERATE IN EXPLOSIVE ATMOSPHERES**

To avoid explosion, do not operate this product in an explosive atmosphere unless it has been specifically certified for such operation.

### **DO NOT OPERATE WITHOUT COVERS**

To avoid personal injury, do not operate this product without covers or panels installed.