

Post Adjustment

C - Conservative
M - Medium
L - Liberal

RUBBER RINGS

- R1--7A-120-100
- R2-7A-120-125
- R3-7A-120-150
- R4-7A-120-175
- R5-7A-120-200
- R6-7A-120-225
- R7-7A-120-275
- R8-7A-120-350
- R9-7A-135
- R10-7A-121-1

BALL GUIDES & ROLL-OVERS

- | | |
|-------------|----------|
| W1-6A-101 | W6-A-383 |
| W2-6A-101-G | W7-A-689 |
| W3-6A-101-K | W8-C-693 |
| W4-6A-265 | W9-C-694 |
| W5-A-149 | |

PLASTIC SHIELDS

Top arch pair 13C-116-1R & 1L
Others: 13A-116-2 to -13
(P1 to P13)

MISC. PARTS & ASSEMBLIES

- 1A-5-Bank Dr. Target
- D-548-5A-1 (Targets Alone 13A-35-1 to -5)
- 1B-3-Bank Dr. Target
- D-580-3F-2 (Targets Alone 13A-20-3)
- 1C-3-Bank Dr. Target
- D-580-3F-2 (Target Alone 13A-11-BL)
- 1D-3-Bank Dr. Target
- D-580-3F-1 (Target Alone 13A-20-1)
- 2-Thumper Cap 13A-38
- 3-Spin Target Assem. A-563-4 (Target & Wire Only 14A-7-3)
- 4-Target Assem. A-461-2Y
- 5- Flipper & Shaft Assem. A-703-Y
- 6-Ball Guide Post 2A-200 (Rubber Ring 7A-125)
- 7-Instruction Plate 14B-5-1
- 8-Shooter Gauge 14A-2-5
- 9-Ball Gate Assem. A-611-R
- 10-Left Gate Assem. A-611-L
- 11-Anti-Return Gate A-471




FIGURE 14. CHEETAH PLAYFIELD PARTS