


# Post Adjustment

C - Conservative

M - Medium

L - Liberal



## RUBBER RINGS

- R1-7A-120-031
- R2-7A-120-100
- R3-7A-120-125
- R4-7A-120-225
- R5-7A-120-250
- R6-7A-120-300
- R7-7A-121
- R8-7A-125

## BALL GUIDES & ROLL-OVERS

- |           |           |
|-----------|-----------|
| W1-6C-231 | W5-6A-101 |
| W2-6B-233 | W6-A-383  |
| W3-B-566  | W7-A-149  |
| W4-B-577  |           |

## PLAYFIELD PLASTIC SHIELDS

- DRACULA SET 13A-109-1 TO - 7  
(P-1 TO P-7)

## MISCELLANEOUS PARTS

1. Roll-Over Button 4B-275
2. Bank Target D-580-4A
3. Bank Target D-580-3A
4. Ball Guide Post 2A-200
5. Thumper Cap 13A-24
6. Flipper & Shaft A-193
7. Instruction Plate 14B-1-1
8. Shooter Gauge 14A-2-1
9. Target Assembly A-461-2
- 9A. Target Assembly A-461-2Y
10. Spin Target A-563-6
11. Anti-Return Gate A-471
12. Bumper Cap 13A-25

FIGURE 8. DRACULA PLAYFIELD PARTS