

C - Conservative  
M - Medium  
L - Liberal

**RUBBER RINGS**

R1-7A-120-100	R5-7A-120-225
R2-7A-120-125	R6-7A-120-250
R3-7A-120-150	R7-7A-120-275
R4-7A-120-200	R8-7A-135

**BALL GUIDES & ROLL-OVERS**

W1-6A-101	W15-A-149
W2-6A-101-B	W16-A-643
W3-6A-101-E	W17-A-777
W4-6A-101-G	W18-A-778
W5-6A-101-N	W19-A-779
W6-6A-101-O	W20-A-780
W7-6A-129	W21-A-828
W8-6A-294	W22-A-829
W9-6A-276	W23-A-858
W10-6A-296	W24-A-859
W11-6B-274	W25-A-860
W12-6B-275	W26-C-775
W13-1B-897	W27-C-776
W14-A-383	

**PLASTIC SHIELDS**

13C-134-1 to -15  
(P1 to P15)

**MISC. PARTS & ASSEMBLIES**

1. 3-Bank Drop Targ. D-823-3B  
(Targets alone 13A-45-B)
2. 5-Bank Drop Targ. D-823-5A  
(Targets alone 13A-35-1 to -5)
3. Extra Ball Gate Assembly B-675
4. (8) Stand-Up Targets  
(A-722-L-2)
5. Ball Gate Assembly  
A-611-L & A-611-R (Rt. & Lt.)
6. One Way Gate Assembly A-471
7. Spin Target Assembly A-563-4
8. Flipper Assembly B-634-1-LY  
and B-634-1-RY (Rt. & Lt.)
9. Ball Guide Post 2A-200  
(Rubber Ring 7A-125)
10. Thumper Cap 4A-317-Y
11. Ball Walker Assembly B-844
12. Ball Guide Rail 4A-110-RT
13. Ball Guide Rail 4A-121-RT
14. Shooter Gauge 14A-2-11
15. Instruction Plate 14B-18-1




FIGURE 22. FREEFALL PLAYFIELD PARTS