


Post Adjustment

C - Conservative

M - Medium

L - Liberal



RUBBER RINGS

R1-7A-120-031

R4-7A-120-100

R2-7A-121-W

R5-7A-120-300

R3-7A-125

BALL GUIDES & ROLL-OVERS

W1-6A-101-G

W6-4A-110-G

W2-6C-230

W7-4A-121-R

W3-A-149

W8-A-581

W4-A-383

W9-4A-224-R

W5-4A-110-R

PLASTIC SHIELDS

TOP ARCH SET 13C-114-1R-&1L

GALAXY SET 13C-114-2-TO-8 (P1 TO P8)

MISC. PARTS & ASSEM'S.

1. 4-BANK TARGET D-548-4A
2. TARGET ASSEMBLY A-469-Y-BL-B
3. THUMPER CAP 13A-12-5
4. ROLLOVER BUTTON 4B-275
5. BALL GATE A-104-R2
6. 1-WAY GATE ASS'Y A-644 (WIRE FORM 6A-257)
7. SPIN TARGET ASS'Y A-563-10 (TARGET & WIRE ONLY 14A-7-9)
8. FLIPPER & SHAFT ASS'Y A-193
9. BALL GUIDE POST 2A-200
10. INSTRUCTION PLATE 14B-3-2
11. SHOOTER GAUGE 14A-2-5

FIGURE 12. GALAXY PLAYFIELD PARTS