

Post Adjustment

C - Conservative
M - Medium
L - Liberal

RUBBER RINGS

- | | |
|---------------|---------------|
| R1-7A-121 | R6-7A-120-250 |
| R2-7A-131 | R7-7A-120-400 |
| R3-7A-120-031 | |
| R4-7A-120-100 | |
| R5-7A-120-125 | |

BALL GUIDES & WIRE FORMS

- | | |
|-----------|-----------|
| W1-6A-101 | W7-A-383 |
| W2-6A-235 | W8-A-581 |
| W3-6A-236 | W9-A-589 |
| W4-6A-237 | W10-A-590 |
| W5-6A-238 | W11-A-591 |
| W6-A-149 | |

PLASTIC SHIELDS

TOP ARCH SET 13C-112-1R & 1LA
PLAYFIELD SET 13A-112-2 TO-7
(P-2 TO P-7)

MISCELLANEOUS PARTS

1. 5-BANK TARGET D-580-5A
2. SPIN TARGET A-563-7
3. THUMPER CAP 13A-29
4. ROLL-OVER BUTTON 4B-275
5. FLIPPER & SHAFT A-193
6. BALL GATE, LEFT A-104-L
7. BALL GATE, RIGHT A-104-R
8. ROLL-OVER BUTTON ASS'Y A-593
9. TARGET ASS'Y A-461-1
10. TOP ARCH RAIL 6B-222
11. INSTRUCTION PLATE 14B-3-1
12. SHOOTER GAUGE 14A-2-4
13. BIG FLIPPER 4B-265




FIGURE 10. HOT HAND PLAYFIELD PARTS