


Post Adjustment

C - Conservative

M - Medium

L - Liberal



RUBBER RINGS

R1-7A-121
R2-7A-120-031
R3-7A-125
R4-7A-120-031

R5-7A-120-125
R6-7A-120-150
R7-7A-120-200
R8-7A-120-250

BALL GUIDES & ROLL-OVERS

W1-A-149
W2-6A-235
W3-6A-140
W4-B-603
W5-B-604

W6-6A-101
W7-4A-121
W8-6A-219
W9-6A-227

PLAYFIELD PLASTIC SHIELDS

TOP ARCH SET 13C-115-1R & 1L
PLAYFIELD SET 13A-115-2 To -7
(P2 To P7)

OTHER PARTS

1. BALL GATE A-104-R1
2. REBOUND RUBBER A-105
3. ROLL-OVER BUTTON 4B-241
4. BANK TARGET D-580-3B
5. BALL GUIDE POST 2A-200
6. THUMPER CAP 13A-24-B
7. FLIPPER & SHAFT A-193
8. TARGET ASSEM. A-461-2
9. SPIN TARGET A-563-3
10. INSTRUCTION PLATE 14B-3-1
11. SHOOTER GAUGE 14A-2-4
12. TOP ARCH RAIL 6B-222
13. ANTI-RETURN GATE A-471

FIGURE 13. MAGIC PLAYFIELD PARTS