

Post Adjustment

**C - Conservative
M - Medium
L - Liberal**

RUBBER RINGS

- R1-7A-120-100
- R2-7A-120-150
- R3-7A-120-175
- R4-7A-120-225
- R5-7A-120-275
- R6-7A-120-350
- R7-7A-135

BALL GUIDES & ROLL-OVERS

- | | |
|-----------|----------------|
| W1-A-149 | W6-A-791 |
| W2-A-783 | W7-A-793 |
| W3-B-784 | W8-A-794 |
| W4-C-785 | W9-6A-101 |
| W5-B-786 | W10-6A-278 |
| W5A-A-764 | W11-6A-279-L&R |
| | W12-A-793 |

PLASTIC SHIELDS

- Top Arch Set 13C-125-1L & 1R
- Nine Ball Set 13C-125-2 to 9
(P1 to P9)

MISC. PARTS & ASSEMBLIES

1. 8 Bank Drop Target D-548-9B
(Targets Alone 13A-45-B)
2. 3 Bank Drop Target D-580-3J
(Targets Alone 13A-11-R & B)
3. 1 Drop Target C-383-3
(Target Alone A-382-1)
4. Stand-Up Target A-721-L1
5. Ball Gate Assembly A-611-R
6. Rebound Bumper Assembly A-790
7. 1 Way Gate Assembly A-471
(Wire Alone 6A-211)
8. Roll-Under Gate Assembly A-791
(Wire Alone 6A-264)
9. Flipper Assembly B-634-R-Y and
B-634-L-Y (Right & Left)
(Rubber Ring 7A-121-Y)
10. Ball Guide Post 2A-200
(Rubber Ring 7A-125)
11. Thumper Cap 13A-43
12. Spin Target Assembly A-792
(Target & Wire Only 14A-11-1)
13. Bumper Cap 13A-44
14. Instruction Plate 14B-3-6
15. Shooter Gauge 14A-2-10




FIGURE 21. NINE BALL PLAYFIELD PARTS